


Pump series SMP self-priming magnetically coupled centrifugal pump

Original operating manual



Version 11335/0325
Print-No.

SCHMITT-Kreiselpumpen GmbH & Co. KG
Einsteinstraße 33
76275 Ettlingen
Germany
Phone: + 49 (0) 7243 / 54 53 - 0
E-Mail: sales@schmitt-pumpen.de
Internet: www.schmitt-pumpen.de

Subject to technical modifications.

Read carefully before use.
Save for future use.



Table of contents

1 About this document	4	5.4.3 Installing the pressure pipe	15
1.1 Target groups	4	5.4.4 Inspection for stress-free pipe connections	15
1.2 Other applicable documents	4	5.5 Electrical connection	15
1.3 Warnings and symbols	5	5.5.1 Connecting the motor	15
2 General safety instructions	6	6 Operation	16
2.1 Intended use	6	6.1 Preparing for commissioning	16
2.2 General safety instructions	6	6.1.1 Check downtimes	16
2.2.1 Product safety	6	6.1.2 Filling and bleeding	16
2.2.2 Obligations of the operating company	6	6.1.3 Check direction of rotation	16
2.2.3 Obligations of personnel	7	6.2 Commissioning	16
2.3 Specific hazards	7	6.2.1 Switching on	16
2.3.1 Electric shock	7	6.2.2 Switching off	17
2.3.2 Hazardous pumped media sprayed out	7	6.3 Shutting down the pump	17
2.3.3 Moving parts	7	6.4 Restoring the pump to service	17
2.3.4 Hot surfaces	8	6.5 Operating the stand-by pump	17
2.3.5 Magnetic field	8	7 Maintenance	18
3 Layout and Function	9	7.1 Inspections	18
3.1 Marking	9	7.2 Servicing	18
3.2 Description	9	7.2.1 Maintenance in accordance with maintenance schedule	18
3.3 Assembly	10	7.2.2 Check the plain bearings and replace them	18
3.4 Magnetic coupling	10	7.2.3 Cleaning the pump	19
4 Transport, Storage and Disposal	11	7.3 Dismounting	20
4.1 Transport	11	7.3.1 Preparations for dismounting	20
4.1.1 Unpacking and inspection on delivery	11	7.3.2 Dismount the pump	20
4.1.2 Lifting	11	7.4 Replacement parts and return	20
4.2 Storage	11	7.5 Installing	21
4.3 Disposal	11	7.5.1 Preparations for installation	21
5 Installation and connection	12	7.5.2 Assembly of the pump	21
5.1 Preparing for installation	12	7.5.3 Install the pump into the system	22
5.1.1 Check operating conditions	12	8 Troubleshooting	23
5.1.2 Preparing the installation site	12	9 Appendix	26
5.1.3 Surface preparation	12	9.1 Parts	26
5.2 Setting up	12	9.1.1 Part numbers and designations	26
5.3 Planning pipelines	12	9.1.2 Part numbers and designations	26
5.3.1 Designing pipelines	12	9.1.3 Drawings	27
5.3.2 Arranging the supports and connections	12	9.2 Installation example	29
5.3.3 Specifying nominal widths	12	9.3 Technical specifications	30
5.3.4 Determine the pipe lengths and installation parameters	13	9.3.1 Ambient conditions	30
5.3.5 Overview of installation conditions for pipelines	14	9.3.2 Total pressure	30
5.3.6 Optimizing changes of cross section and direction	15	9.3.3 Installation dimensions	30
5.3.7 Providing safety and control devices (recommended)	15	9.3.4 Tightening torques	30
5.4 Connecting the pipes	15	9.3.5 Pump housing fill volume	30
5.4.1 Keeping the piping clean	15	9.3.6 Flow rate, delivery head, suction head after 180 s and minimum flow rate	31
5.4.2 Installing suction pipe	15	9.3.7 Weights	31
		9.3.8 Cleaning agents	31
		9.4 Maintenance schedule	32

9.5	Declaration of conformity	33
-----	---------------------------	----

List of figures

Fig. 1	Name plate (example)	9
Fig. 2	SMP layout	10
Fig. 3	Attach the lifting gear to the modular pump (illustration of general principle)	11
Fig. 4	Pipe lengths and installation parameters	13
Fig. 5	Permissible (ü) and impermissible(X) installation conditions	14
Fig. 6	Components of the plain bearing	19
Fig. 7	Prepare an O-ring and flange	21
Fig. 8	Parts (sectional drawing)	27
Fig. 9	Parts (exploded drawing)	28
Fig. 10	Installation example	29
Fig. 11	Total pressure, pump head material PP	30
Fig. 12	Installation dimension	30

List of tables

Tab. 1	Other application documents, purpose and where found	4
Tab. 2	Warning signs and consequences if disregarded	5
Tab. 3	Symbols and their meaning	5
Tab. 4	Measures to be taken if the pump is shut down	17
Tab. 5	Measures depending on the behavior of the pumped liquid	17
Tab. 6	Fault/number assignment	23
Tab. 7	Troubleshooting list	25
Tab. 8	Designation of components according to part numbers	26
Tab. 9	Designation of spare parts by spare part no.	26
Tab. 10	Ambient conditions	30
Tab. 11	Total pressure	30
Tab. 12	Tightening torques of casing screws	30
Tab. 13	Pump housing fill volume	30
Tab. 14	Flow rate, delivery head, suction head after 180 s and minimum flow rate	31
Tab. 15	Weights	31
Tab. 16	Maintenance schedule	32

1 About this document

This manual:

- is an integral part of the pump
- applies to all series referred to
- describes safe and proper operation during all operating phases

1.1 Target groups


Operating company

- Responsibilities:
 - Always keep this manual accessible where the device is used on the system.
 - Ensure that employees read and observe this document, particularly the safety instructions and warnings, and the documents which also apply.
 - Observe any additional country-specific rules and regulations that relate to the system.

Qualified personnel, fitter





- Mechanics qualification:
 - Qualified employees with additional training for fitting the respective pipework
- Electrical qualification:
 - Qualified electrician
- Transport qualification:
 - Qualified transport specialist
- Responsibility:
 - Read, observe and follow this manual and the other applicable documents, especially all safety instructions and warnings.

1.2 Other applicable documents



Document/purpose	Where found
The following documents are available online: <ul style="list-style-type: none"> • Resistance lists <ul style="list-style-type: none"> – Resistance of materials used to chemicals • Data sheet <ul style="list-style-type: none"> – Technical specifications, operating conditions, dimensions • www.schmitt-pumpen.de/en/services/downloads 	
Spare parts list <ul style="list-style-type: none"> • Ordering spare parts 	Documentation included
Sectional drawing <ul style="list-style-type: none"> • Sectional drawing, part numbers, component designations 	
Documentation for the drive <ul style="list-style-type: none"> • Technical documentation for drives 	
Declaration of conformity <ul style="list-style-type: none"> • Conformity with standards • (→ 9.5 Declaration of conformity, Page 33). 	

Tab. 1 Other application documents, purpose and where found

1.3 Warnings and symbols


Warning sign	Level of risk	Consequences if disregarded
	immediate acute risk	Death, serious bodily harm
	potentially acute risk	Death, serious bodily harm
	potentially hazardous situation	Minor injury
	potentially hazardous situation	Material damage

Tab. 2 Warning signs and consequences if disregarded

Symbol	Meaning
	Safety warning sign ▶ Take note of all information highlighted by the safety warning sign and follow the instructions to avoid injury or death.
▶	Instruction
1., 2., ...	Multiple-step instructions
✓	Precondition
→	Cross reference
	Information, notes

Tab. 3 Symbols and their meaning

2 General safety instructions

 The manufacturer accepts no liability for damages caused by disregarding any of the documentation.

2.1 Intended use


- Only use the pump with suitable media. Pump parts in contact with media must be resistant to the media. (→ Order specification).
- Adhere to the operating limits and size-dependent minimum flow rates.
- Avoid dry running:
Initial damage, such as destruction of plain bearings, seals and plastic parts, will occur within a few seconds.
 - Make sure the pump is only operated when filled with the conveyed fluid and never operated when not filled with the pumped liquid.
 - Ensure that there are no excessively high amounts of gas in the pumping medium.
 - Ensure that the pump is operated only within the permissible operating range.
 - Ensure that the use of shut-off valves or filters does not cause the pressure on the inlet side of the pump to be too low.
- Avoid cavitation:
 - Fully open the suction-side fitting, if installed.
 - Do not open the pressure-side fitting beyond the agreed operating point.
- Avoid overheating:
 - Do not operate the pump while the pressure-side fitting is closed.
 - Observe the minimum flow rate (→ [9.3 Technical specifications, Page 30](#)).
- Avoid damage to the motor:
 - Do not open the pressure-side fitting beyond the agreed operating point.
 - Note the maximum permissible number of times the motor can be switched on per hour (→ manufacturer's specifications).
- Consult with the manufacturer regarding any other use of the device.

Prevention of obvious misuse (examples)

- Observe pump limits of use regarding temperature, pressure, flow and speed (→ [9.3 Technical specifications, Page 30](#)).
- The power consumption of the pump increases as the specific gravity of the pumped fluid increases. Adhere to the permissible specific gravity in order to eliminate the possibility that the pump and motor become overloaded (→ [9.3 Technical specifications, Page 30](#)). A lower specific gravity is permissible. Adapt the auxiliary systems accordingly.

- Do not convey any media containing solids.
- The type of installation should be selected only in accordance with these operating instructions. For example, the following are not allowed:
 - Hanging pumps in the pipe
 - Overhead installation
 - Installation in the immediate vicinity of extreme heat or cold sources
 - Installation too close to a wall
 - Vertical installation

2.2 General safety instructions

 Observe the following regulations before carrying out any work.

2.2.1 Product safety

The pump has been built according to state-of-the-art technology and the recognized technical safety regulations. Nevertheless, operation of the pump can still put the life and health of the user or third parties at risk or damage the pump or other property.

- Operate the pump only if it is in perfect technical condition and use it only as intended, staying aware of safety and risks, and in adherence to the instructions in this manual.
- Keep this manual and all other applicable documents complete, legible and accessible to personnel at all times.
- Refrain from any procedures and actions that would pose a risk to personnel or third parties.
- In the event of any safety-relevant faults, shut down the pump immediately and have the fault corrected by appropriate personnel.
- In addition to the entire documentation for the product, comply with statutory or other safety and accident-prevention regulations and the applicable standards and guidelines in the country where the pump is operated.

2.2.2 Obligations of the operating company

Safety-conscious working

- Operate the pump only if it is in perfect technical condition and use it only as intended, staying aware of safety and risks, and in adherence to the instructions in this manual.
- Ensure that the following safety aspects are observed and monitored:
 - Intended use
 - Statutory or other safety and accident-prevention regulations
 - Safety regulations governing the handling of hazardous substances
 - Applicable standards and guidelines in the country where the pump is operated
 - Applicable guidelines of the operator
- Make personal protective equipment available.

Qualified personnel

- Make sure all personnel tasked with work on the pump have read and understood this manual and all other applicable documents, especially the safety, maintenance and repair information, before they start any work.
- Organize responsibilities, areas of competence and the supervision of personnel.
- Make sure that trainee personnel only work on the pump under supervision of specialist technicians.
- All activities may be carried out only by specialists who hold the required qualifications:

Actions	Required qualified personnel
Mechanical work (installation, maintenance, servicing)	Skilled mechanic
Electrical work (electrical installation)	Qualified electrician
All further work	Instruction by the user/owner

Safety equipment

- Provide the following safety equipment and verify its functionality:
 - For hot, cold and moving parts: pump safety guarding provided by the customer
 - For pumps without capability to run dry: Dry run protection

Warranty

- Obtain the manufacturer's approval prior to carrying out any modifications, repairs or alterations during the warranty period.
- Only use genuine parts or parts that have been approved by the manufacturer.

2.2.3 Obligations of personnel

- All directions given on the pump must be followed (and kept legible), e.g. the arrow indicating the sense of rotation and the markings for fluid connections.
- Pump and components:
 - Do not step on them or use as a climbing aid
 - Do not use them to support boards, ramps or beams
 - Do not use them as a fixing point for winches or supports
 - Do not use them for storing paper or similar materials
- Do not remove the safety guarding for hot, cold or moving parts during operation.

- If necessary, use protective equipment for the specific application:
 - Helmet
 - Safety gloves
 - Safety goggles
 - Gloves
 - Further protective equipment depending on the medium being pumped
- Only carry out work on the pump while it is not running.
- Before all installation and maintenance work, disconnect the motor from the mains and secure it against being switched back on again.
- Never reach into the suction or pressure-side flange.
- Following all work on the pump, refit safety devices in accordance with the instructions and bring into service.
- Do not make any modifications to the device.

2.3 Specific hazards

2.3.1 Electric shock

In the event of contact with live parts (e.g. wires in the terminal box of the electric motor), there is a risk of electric shock resulting in serious injury or death.

- All electrical work must be carried out by qualified electricians only.
- Before all work on the electrical system, disconnect the motor from the mains and secure against being switched back on again.

2.3.2 Hazardous pumped media sprayed out

Pumped media can be toxic and hot and can be sprayed out. In the event of contact, there is a risk of burns and skin rashes.

- When handling hazardous fluids (e.g. hot, flammable, explosive, toxic, hazardous to health or the environment), observe the safety regulations for the handling of hazardous substances.
- Allow the pump to cool completely before commencing any work and then depressurize it.
- Use protective equipment for any work on the pump.
- Empty the pump during maintenance and repair work.
- Safely collect the fluid and dispose of it in accordance with environmental regulations.

2.3.3 Moving parts

Moving parts (e.g. shaft, impeller, coupling) present a risk of fatal injury due to being dragged in, crushed or trapped.

- Do not touch the pump when it is running.
- Do not carry out any work on the pump when it is running.
- Maintain an adequate distance from moving parts.
- When performing installation and maintenance work, disconnect the motor from the mains and secure it against being switched back on again.
- (If present) ensure contact guard is fitted after work on the pump.

2.3.4 Hot surfaces

During operation, high temperatures are generated on the surfaces of the housing. Even after switching off, the surfaces of the housing can still be hot and can cool down only slowly. There is a risk of burns when touching hot surfaces.

- Do not touch the pump when it is running.
- Allow the pump to cool completely before commencing any work.
- Wear protective gloves.

2.3.5 Magnetic field

The magnetic field of the magnetic coupling can destroy products and devices that are sensitive to magnets. These include electronic implants (such as pacemakers), digital watches, calculators, hard drives, credit cards and ID cards. For persons with electronic implants there is a danger to life.

- Do not allow persons with electronic implants to work on the pump or on magnetic parts.
- Secure the work place and if necessary cordon off:
 - Ensure that persons with electronic implants maintain a safe distance > 1 m
 - Make sure that no magnetizable metal parts are attracted by the pump's magnetic coupling.
 - Make sure that parts of the magnetic coupling are not attracted by the magnetizable metal parts
- Keep magnetizable objects a safe distance > of 150 mm away from the magnetic coupling.

3 Layout and Function

3.1 Marking




Fig. 1 Name plate (example)

- 1 Type
- 2 Serial number
- 3 Pump series
- 4 Size
- 5 Pump material

3.2 Description

Self-priming and magnetically coupled centrifugal pump in modular design:

- 2 housing chambers
- Media-lubricated plain bearings
- Direction of conveying
 - Flange, suction side, axial (suction pipe vertical)
 - Flange, pressure side, vertical
- Conveying from open or closed, but depressurized tanks, pits or vessels

3.3 Assembly




Fig. 2 SMP layout


- | | | |
|-------------------------|--------------------------------------|----------------|
| 1 Flange, pressure side | 5 Housing (consisting of 2 chambers) | 9 Terminal box |
| 2 Filler opening | 6 Impeller (concealed) | 10 Motor |
| 3 Flange, suction side | 7 Pump support | |
| 4 Exhaust opening | 8 Magnetic coupling (hidden) | |


3.4 Magnetic coupling

Pumps with magnetic couplings are hermetically sealed and leaktight. Power transmission from the motor is non-contact through an enclosed and hermetically sealed rear cover on the impeller.

4 Transport, Storage and Disposal

4.1 Transport

 The user/owner is responsible for the transport of the pump.

 Weight specification (→ 9.3 Technical specifications, Page 30).

4.1.1 Unpacking and inspection on delivery

1. Unpack the pump/machine drive on delivery, and inspect it for transport damage.
2. Check completeness and accuracy of delivery.
3. Ensure that the information on the name plate agrees with the order/design data.
4. Report any transportation damage to the manufacturer immediately.
5. Dispose of packaging material according to local regulations.

4.1.2 Lifting

DANGER

Death or limbs crushed as a result transported items falling over!

- ▶ Use lifting gear appropriate for the total weight to be transported.
- ▶ Attach lifting gear in accordance with the following diagram.
- ▶ Do not stand under suspended loads.




Fig. 3 Attach the lifting gear to the modular pump (illustration of general principle)

1. Attach lifting gear in accordance with the above diagram.
2. Lift the modular pump appropriately.

4.2 Storage


NOTE

Material damage due to inappropriate storage!

- ▶ Store the pump properly.

1. Rinse and empty the pump if necessary.
2. Seal all openings with blind plugs or plastic covers.
3. Make sure the storage room meets the following conditions:
 - Dry
 - Frost-free
 - Vibration-free
 - UV protected
4. Rotate the pump shaft once a month.
5. Make sure the shaft and bearing change their rotational position in the process.

4.3 Disposal

 Plastic parts can be contaminated by poisonous or radioactive pumped liquids to such an extent that cleaning will be insufficient.

WARNING

Risk of poisoning and environmental damage by the pumped liquid!

- ▶ Use personal protective equipment when carrying out any work on the pump.
 - ▶ Prior to the disposal of the pump:
 - Collect and damage any escaping pumped liquid in accordance with local regulations.
 - Neutralize residues of pumped liquid in the pump.
 - ▶ Remove plastic parts and damage them in accordance with local regulations.
-
- ▶ Dispose of the pump in accordance with local regulations.

5 Installation and connection

NOTE

Material damage caused by dirt!

- ▶ Do not remove the transport seals until immediately before installing the pump.
- ▶ Do not remove any covers or transport and sealing covers until immediately before connecting the pipes to the pump.

5.1 Preparing for installation

5.1.1 Check operating conditions

- ▶ Ensure the required operating conditions are met:
 - Resistance of body and seal material to the medium (→ resistance lists).
 - Required ambient conditions (→ 9.3.1 Ambient conditions, Page 30).

5.1.2 Preparing the installation site

- ▶ Ensure the installation site meets the following conditions:
 - Pump is freely accessible from all sides
 - Sufficient space for the installation/removal of the pipes and for maintenance and repair work, especially for the removal and installation of the pump
 - Pump not exposed to external vibration (damage to bearings)
 - Pump not exposed to external corrosive influences
 - Frost protection
 - The head of the pump is not exceeded.


5.1.3 Surface preparation

- ✓ Aids, tools, materials:
 - Spirit level
- ▶ Make sure the surface meets the following conditions:
 - Level and horizontal
 - Clean (no oil, dust or other impurities)
 - Capable of bearing the weight of the machine drive and all operating forces
 - Ensures the stability of the machine drive

5.2 Setting up

1. Lift up the machine drive (→ 4.1 Transport, Page 11).
2. Put down the machine drive at the place of installation.
3. Screw the fastening screws into the flange and tighten them.

5.3 Planning pipelines

 Note the installation example (→ 9.2 Installation example, Page 29).

Water hammer may damage the pump or the system. Plan the pipes and fittings as far as possible to prevent water hammer occurring.

5.3.1 Designing pipelines

- ▶ Plan pipes safely:
 - No pulling or thrusting forces
 - No bending moments
 - Adjust for changes in length due to temperature changes (compensators, expansion shanks)
 - Avoid bends close to the pressure-side flange

5.3.2 Arranging the supports and connections


NOTE

Material damage due to excessive forces and torques on the pump!

- ▶ Ensure pipe connection without stress.
- ▶ Do not exceed the max. permissible tightening torque for the flange bolts (→ 9.3.4 Tightening torques, Page 30).

1. Support pipes in front of the pump.
2. Ensure the pipe supports will always allow expansion and contraction of the pipes.

5.3.3 Specifying nominal widths

 Keep the flow resistance in the pipes as low as possible.

1. Make sure the nominal suction line width is equal to the nominal suction flange width.
2. Make sure the nominal pressure line width is not smaller than the nominal discharge flange width.

5.3.4 Determine the pipe lengths and installation parameters





Fig. 4 Pipe lengths and installation parameters

- A DN_s
- B ≥ 0.5 m
- C ≥ 1.5 x DN_s
- D DN_d
- E > 5 x DN_d

► Observe recommended minimum values when installing the pump. Note the installation example (→ [9.2 Installation example, Page 29](#)).

 Pressure side: Shorter lengths are possible, but may result in increased noise development.

5.3.5 Overview of installation conditions for pipelines




Fig. 5 Permissible (✓) and impermissible (X) installation conditions

- | | |
|--|------------------------------------|
| 1 Air pocket formation in the suction line | 3 Air bubbles in the pumped medium |
| 2 Vortex in the pumped medium | |

► Comply with the installation conditions of the pipelines.

5.3.6 Optimizing changes of cross section and direction

1. Avoid radii of curvature of less than 1.5 times the nominal pipe diameter.
2. Avoid abrupt changes of cross-section along the piping.

5.3.7 Providing safety and control devices (recommended)

Avoid contamination

- ▶ Install a dirt strainer with mesh size <3 mm at the inlet of the suction pipe.

Avoid reverse running

1. Install a foot valve or check valve between the pressure-side flange and shut-off valve to ensure that the medium does not flow back after the pump is switched off.
2. In order to enable venting, include vent connection between the pressure-side flange and foot valve or check valve.

Make provisions for isolating and shutting off the pipes



For maintenance and repair work.

- ▶ Provide shut-off valves in the suction pipe and pressure line.

Dry run protection by measuring the operating conditions

- ▶ Provide monitoring sensors for both pressure and flow rate, to protect the pump against dry running and consequential damage.

5.4 Connecting the pipes

NOTE

Material damage due to excessive forces and torques on the pump!

- ▶ Ensure pipe connection without stress.

5.4.1 Keeping the piping clean

NOTE

Material damage due to impurities in the pump!

- ▶ Make sure no impurities can enter the pump.
- ▶ Clean all piping parts and fittings prior to assembly.

5.4.2 Installing suction pipe

1. Remove the transport and sealing covers from the pump.
2. Fit suction pipe stress-free and sealed.
3. Avoid gas cavities:
 - Always lay the suction pipe rising.
 - Install bends with an angle < 90°.
 - Do not install the suction pipe near whirlpools or supply lines.

5.4.3 Installing the pressure pipe

1. Remove the transport and sealing covers from the pump.
2. Position the pressure-side flange facing upwards, so as to allow the pump head to be vented.
3. Fit the pressure line stress-free and sealed.
4. Install the foot valve under the following operating conditions:
 - The outlet of the suction pipe is at least 10 m above the tank fill level height
 - Differential head > 15 m

5.4.4 Inspection for stress-free pipe connections

- ✓ Piping installed and cooled down

 1. Disconnect the pipe connections from the pump.
 2. Check whether the pipes can be moved freely in all directions within the expected range of expansion.
 3. Make sure that the connections are parallel.
 4. Reconnect the pipe connections to the pump.

5.5 Electrical connection


DANGER

Risk of electrocution!

- ▶ All electrical work must be carried out by qualified electricians only.
- ▶ Before all work on the electrical system, disconnect the motor from the mains and secure against being switched back on again.

5.5.1 Connecting the motor



Follow the instructions of the motor manufacturer.

1. Connect the motor according to the connection diagram.
2. Make sure no danger arises due to electric power.
3. Install an EMERGENCY STOP switch.


6 Operation

6.1 Preparing for commissioning

6.1.1 Check downtimes

- ▶ Before starting up the pump, check the downtime and perform the following actions:
 - Check the fill level.
 - If the hydraulic parts are dirty, clean them.
 - Check that the impeller runs freely.

6.1.2 Filling and bleeding

 The pump housing is filled with conveyed fluid. During commissioning, the suction line is filled fully by the pump and vented via the vent line. Additional measures for venting are not required.

1. Unscrew the filler cap.
2. Pour in the conveyed fluid. Note the fill volumes (→ 9.3.5 Pump housing fill volume, Page 30).
3. Screw the filler cap back on.

6.1.3 Check direction of rotation

NOTE

Material damage as a result of dry running!

- ▶ Make sure the pump is filled properly.
1. Switch on motor for max. 2 seconds and switch it off again immediately.
 2. Visually check the direction of rotation of the motor fan impeller and make sure that the direction of rotation of the motor matches the direction arrow on the pump casing.
 3. If the sense of rotation is different: Change over the two phases (→ 5.5 Electrical connection, Page 15).

6.2 Commissioning

6.2.1 Switching on

- ✓ Pump set up and connected properly
- ✓ Motor set up and connected properly
- ✓ All connections stress-free and sealed
- ✓ All safety equipment installed and tested for functionality
- ✓ Pump prepared, filled and vented correctly
- ✓ Tank fill sufficient

NOTE

Risk of cavitation if suction flow is restricted!

- ▶ Open the suction-side fitting and do not use it to regulate the flow, if installed.
- ▶ Do not open the pressure-side fitting beyond the operating point.

NOTE

Material damage due to overheating!

- ▶ Do not operate the pump for long periods with the pressure-side fitting closed.
- ▶ Observe the minimum flow rate (→ 9.3.6 Flow rate, delivery head, suction head after 180 s and minimum flow rate, Page 31).

NOTE

Material damage as a result of dry running!

- ▶ Make sure the pump is filled properly.
1. Open the suction-side fitting, if installed.
 2. Close the pressure-side fitting.
 3. Open the exhaust line fitting.
 4. Switch on the motor and check it for smooth running.
 5. Make sure that the suction pipe and pump are vented fully. Check the vacuum gauge.
Gas escapes through the exhaust line.
 6. Once as the suction line is vented, close the vent line and slowly open the pressure-side valve.
 7. Make sure temperature change is smaller than 5 K/min for pumps with hot fluids.
 8. After the initial stress due to the pressure and operating temperature, check that the pump is not leaking.
 9. If leaks are present at the housing seals or flanges, proceed as follows:
 - Switch off motor.
 - Close the control valves.
 - Remedy the leaks.

6.2.2 Switching off

- ✓ Pressure-side fitting closed (recommended)
- 1. Switch off motor.
- 2. Check all connecting screws and tighten them to the specified torque (→ 9.3.4 Tightening torques, Page 30).

6.3 Shutting down the pump

- ▶ Take the following measures whenever the pump is shut down:

Pump is	Measure
shut down	▶ Take measures appropriate for the fluid (→ Tab. 5 Measures depending on the behavior of the pumped liquid, Page 17).
...emptied	▶ Close suction and pressure-side fitting.
...dismounted	▶ Isolate the motor from its power supply and secure it against unauthorized switch-on.
...put into storage	▶ Note measures for storage (→ 4.2 Storage, Page 11).

Tab. 4 Measures to be taken if the pump is shut down

Behavior of the pumped liquid	Duration of shutdown (depending on process)	
	Short	Long
Crystallized or polymerized, solids sedimenting	▶ Flush the pump.	▶ Flush the pump.
Solidifying/ freezing, non-corrosive	▶ Heat up or empty the pump and containers.	▶ Empty the pump and containers.
Solidifying/ freezing, corrosive	▶ Heat up or empty the pump and containers.	▶ Empty the pump and containers.
Remains liquid, non-corrosive	–	–
Remains liquid, corrosive	–	▶ Empty the pump and containers.


Tab. 5 Measures depending on the behavior of the pumped liquid

6.4 Restoring the pump to service

- ▶ Complete all steps as for commissioning (→ 6.2 Commissioning, Page 16).

6.5 Operating the stand-by pump

- ✓ Stand-by pump filled and bled
- ✓ Suction pipe not vented

 Operate the stand-by pump at least once a week.


1. Fully open the suction-side fitting, if installed.
2. Open pressure-side fitting far enough so that the stand-by pump operating temperature is achieved and heating is even (→ 6.2.1 Switching on, Page 16).

7 Maintenance


Opening the pump casing invalidates the warranty.

When used for the intended purpose the bearings and seals are virtually free of wear and will not require replacement during the warranty period.

Maintenance and repair work should be undertaken in consultation with Schmitt Kreiselpumpen. The chapter describes maintenance not within the warranty period.


 Maintenance during the warranty period will be performed by Schmitt Kreiselpumpen. Submit evidence of conveyed medium on request (DIN safety data sheet or confirmation of decontamination).

7.1 Inspections

 The inspection intervals depend on the operational strain on the pump.

1. Check at appropriate intervals:
 - Adherence to the minimum flow rate
 - Normal operating conditions unchanged
 - Tank fill level
2. For trouble-free operation, always ensure the following:
 - No dry running
 - No leaks
 - No cavitation
 - Shut-off valve open on the suction side, if installed
 - Free and clean filters
 - Sufficient pump inlet pressure
 - No unusual running noises or vibrations
 - No parting of magnetic coupling


7.2 Servicing

 Plain bearings are subject to natural wear and tear which is heavily dependent on the respective operating conditions. It is therefore not possible to make general statements about the operating life.

7.2.1 Maintenance in accordance with maintenance schedule

- ▶ Perform maintenance work in accordance with the maintenance schedule ([→ 9.4 Maintenance schedule, Page 32](#)).

7.2.2 Check the plain bearings and replace them

 When changing the plain bearings, refer to the drawings ([→ 9.1.3 Drawings, Page 27](#)).

Request spare parts from the manufacturer ([→ 7.4 Replacement parts and return, Page 20](#)).

When checking the plain bearings, inspect the following parts for damage and exchange them as needed:

- Impeller
- Housing
- Seals and O-rings

Dismount the pump

To allow the plain bearings to be checked and replaced, disassemble the pump.

- ✓ Prepared for disassembly ([→ 7.3.1 Preparations for dismounting, Page 20](#)).
1. Remove the hexagon nuts and washers (12) from the hexagon socket screws (2).
 2. Remove the hexagon socket screws (2).
 3. Remove the front pump housing from the rear pump housing (10).
 4. Remove the housing seal (6) and check it for damage. If necessary dispose of the housing seal and fit a new part.
 5. Remove the partition (7).
 6. Remove the filter (9), check it for dirt and clean it if necessary.
 7. Remove the O-ring (8) and check it for damage. If necessary dispose of the O-ring and fit a new part.
 8. Remove the hexagon screws (18).
 9. Remove the rear pump housing (10).
 10. Remove the O-ring (15) and check it for damage. If necessary dispose of the O-ring and fit a new part.
 11. Pull the rear cover (16) with impeller (13) off the external magnet (19).
 12. Remove the seal from the pump support (17) and check it for damage. If necessary dispose of the seal and fit a new part.

Check the plain bearings and replace them




Fig. 6 Components of the plain bearing

- 10-1 Bearing ring, rear housing
- 13-1 Bearing ring, impeller
- 14 Bearing bush
- 16-1 Bearing ring, rear cover
- 16-2 Fixed axle in the rear cover

NOTE

Material damage due to incorrect use!

- ▶ Inspect the ceramic parts of the plain bearings carefully; do not strike them or knock them.
13. Check the bearing ring (10-1) on the rear pump housing (10) for damage. In case of damage, dispose of the entire rear housing and fit a new part.
 14. Remove the impeller (13) from the rear cover (16).
 15. Check the bearing ring (13-1) on the impeller (13) for damage. In case of damage, dispose of the entire impeller and fit a new part.
 16. Check the impeller (13) for dirt and damage. If necessary clean the impeller or dispose of it, and fit a new part.
 17. Check the bearing bush (14) for damage. In the event of damage, dispose of the bearing bush and fit a new part.
 18. Check the bearing ring (16-1) and the fixed axle (16-2) on the rear cover (16) for damage. In case of damage, dispose of the entire rear cover and fit a new part.
 19. If necessary, clear the through holes and relief holes.

Installing the pump

20. Slide the bearing bush (14) with impeller (13) onto the fixed axle in the rear cover (16).
21. Install the O-ring (15) in the rear cover (16).
22. Install the seal in the pump support (17).
23. Insert the rear cover (16) together with the impeller (13) into the external magnets (19).
24. Install the rear housing (10) on the pump support (17) and tighten the hexagon screws (18) hand-tight.
25. Install the filter (9).
26. Install the O-ring (8).
27. Install the partition (7).
28. Install the housing seal (6).
29. Install the front pump housing on the rear pump housing (10).
30. Install the hexagon socket screws (2).
31. Tighten the hexagon nuts with washers (12) and hexagon screws (18) crosswise (→ 9.3.4 Tightening torques, Page 30).
32. Spin the motor fan impeller and make sure that the impeller (13) runs freely in the plain bearings.

7.2.3 Cleaning the pump

NOTE

High water pressure or spray water can cause material damage!

- ▶ Do not direct water jets or steam jets into the opening of the flange.
- ▶ Regularly clean the pump to remove heavy dirt.

7.3 Dismounting

WARNING

Risk of injury due to heavy components!

- ▶ Pay attention to the component weight. Lift and transport heavy components using suitable lifting gear.
- ▶ Set down components safely and secure them against overturning or rolling away.

WARNING

Risk of injury during disassembly!

- ▶ Secure the pressure-side shut-off valve against accidental opening.
- ▶ Wear protective gloves, components can become very sharp-edged due to wear or damage.
- ▶ Observe the manufacturer's specifications (e.g. for the motor).

NOTE


Material damage due to incorrect dismounting/installation of the pump!

- ▶ Only specialist mechanics should complete dismounting/installation work.

7.3.1 Preparations for dismounting

- ✓ Pump is depressurized
 - ✓ Pump completely empty, flushed and decontaminated
 - ✓ Electrical connections disconnected and motor secured against switch-on
 - ✓ Pump cooled down
 - ✓ Pressure gauge lines, pressure gauge and fixtures dismounted
1. Dismantle the pipes on the suction and pressure side.
 2. Remove pump from the system.
 3. When dismounting, observe the following:
 - Mark the precise orientation and position of all components before dismounting them.
 - Dismount components concentrically without canting.

7.3.2 Dismount the pump

-  Following the drawings for disassembly (→ 9.1.3 Drawings, Page 27).


NOTE

Material damage, fragile components!


- ▶ Perform disassembly carefully, and do not strike or knock the fragile ceramic parts of the plain bearing.
1. Remove the hexagon nuts and washers (12) from the hexagon socket screws (2).
 2. Remove the hexagon socket screws (2).

3. Remove the front pump housing from the rear pump housing (10).
4. Unscrew the flange (3).
5. Remove the O-ring (4).
6. Unscrew the filler cap with O-ring (5).
7. Unscrew the exhaust cap (1).
8. Remove the housing seal (6).
9. Remove the partition (7).
10. Remove the filter (9).
11. Remove the O-ring (8).
12. Remove the hexagon screws (18).
13. Remove the rear pump housing (10).
14. Unscrew the flange (11).
15. Remove the O-ring (12).
16. Remove the O-ring (15).
17. Pull the rear cover (16) with impeller (13) off the external magnet (19).
18. Remove the impeller (13) from the rear cover (16).
19. Remove the seal from the pump support (17).
20. Remove the hexagon screws on the motor flange.
21. Remove the pump support (17).
22. Remove the fastening screw from the external magnet (19).
23. Pull the external magnet (19) off the motor shaft.

7.4 Replacement parts and return

1. Have the following information as shown on the name plate ready to hand when ordering spare parts (→ 3.1 Marking, Page 9).
 - Serial number
 - Type
 2. Please complete and enclose the confirmation of decontamination for returns (→ www.schmitt-pumpen.de/sites/default/files/2020-10/Dekontaminationsnachweis_en.pdf).
- 
3. Use only spare parts from SCHMITT (E-Mail: sales@schmitt-pumpen.de).

7.5 Installing

 Install components concentrically and without tilting in accordance with the markings applied.

WARNING

Risk of injury due to heavy components!

- ▶ Pay attention to the component weight. Lift and transport heavy components using suitable lifting gear.
- ▶ Set down components safely and secure them against overturning or rolling away.

WARNING

Risk of injury during assembly!

- ▶ Observe the manufacturer's specifications (e.g. for the motor).

NOTE

Material damage due to incorrect dismounting/installation of the pump!

- ▶ Only specialist mechanics should complete dismounting/installation work.

NOTE

Material damage due to unsuitable components!

- ▶ Always replace lost or damaged screws with screws of the same strength where required.
- ▶ Only replace seals with seals of the same material.

NOTE

Material damage, fragile components!

- ▶ Install ceramic parts of the plain bearing and magnets of the magnetic coupling with care, do not strike them or knock them.

7.5.1 Preparations for installation

1. When installing please observe:
 - Replace worn parts with genuine spare parts.
 - Replace seals, inserting them in such a way that they are unable to rotate.
 - Do not apply synthetic or mineral oil, grease or cleaning agents to elastomer components.





Fig. 7 Prepare an O-ring and flange

2. Carefully expand the O-ring (4) somewhat.
3. Using a small brush, grease the inner groove in the flange (3) with Vaseline.

7.5.2 Assembly of the pump

 Following the drawings for assembly (→ 9.1.3 Drawings , Page 27).

Note the correct tightening torque for assembly (→ 9.3.4 Tightening torques, Page 30).

Preparing the impeller for installation

The impeller with the bearing bush, O-ring and rear cover are assembled as a complete unit, so as to avoid material damage during the following installation operations.

1. Make sure that the plain bearing rings on the impeller (13), rear cover (16) and rear housing (10) are undamaged.
2. Slide the bearing bush (14) with impeller (13) onto the fixed axle in the rear cover (16).
3. Install the O-ring (15) on the rear cover (16).
4. Put the unit safely aside.

Installing the pump

5. Slide the external magnet (19) on the motor shaft.
6. Set the correct installation dimension **A** at the end of the motor shaft and external magnet (19) ([→ 9.3.3 Installation dimensions, Page 30](#)).
7. Tighten the fastening screw on the external magnet (19).
8. Insert the external magnet (19) into the pump support (17).
9. Install the pump support (17) on the motor flange. Orient the motor so that the terminal box can be operated at the installation location.
10. Tighten the hexagon screws on the motor flange crosswise.
11. Install the seal in the pump support (17).
12. Insert the unit of the rear cover (16) together with the impeller (13) into the external magnets (19).
13. Install the O-ring (15).
14. Install the O-ring (12).
15. Screw on the flange (11).
16. Install the rear pump housing (10) on the pump support (17) and tighten the hexagon screws (18) hand-tight.
17. Install the filter (9).
18. Install the O-ring (8).
19. Install the partition (7).
20. Install the housing seal (6).
21. Screw on the exhaust cap (1).
22. Screw on the filler cap with O-ring (5).
23. Press the O-ring (4) into the inner groove of the flange (3).
24. Screw on the flange (3).
25. Install the front pump housing on the rear pump housing (10).
26. Install the hexagon socket screws (2).
27. Tighten the hexagon nuts with washers (12) and hexagon screws (18) crosswise.
28. Spin the motor fan impeller and make sure that the impeller (13) runs freely in the plain bearings.

7.5.3 Install the pump into the system

- ▶ Install the pump in the system. ([→ 5 Disposal, Page 12](#)).

8 Troubleshooting

If faults occur which are not specified in the following table or cannot be traced back to the specified causes, please consult the manufacturer.

Possible faults are identified by a fault number in the table below. This number identifies the respective cause and remedy in the troubleshooting list.

Fault	Number
Pump not pumping	1
Pumping rate insufficient	2
Pumping rate excessive	3
Pumping pressure insufficient	4
Pumping pressure excessive	5
Pump running roughly / loud noises / vibration	6
Pump leaks	7
Excessive motor power uptake	8
Housing temperature too high	9

Tab. 6 Fault/number assignment

Fault number									Cause	Remedy
1	2	3	4	5	6	7	8	9		
X	-	-	-	-	-	-	-	-	Suction pipe and/or pressure line closed by fitting	▶ Open the fitting.
X	-	-	-	-	-	-	-	-	Transport and sealing cover still in place	▶ Remove the transport and sealing cover. ▶ Dismount the pump and inspect it for dry-running damage.
X	X	-	-	-	-	-	-	-	Suction pipe too long	▶ Shorten suction pipe.
X	X	-	-	-	-	-	-	-	Pump flange deformed or damaged	▶ Change the pump flange.
X	X	-	X	-	-	-	-	-	Motor speed too low	▶ Compare the required motor speed with the specifications on the pump type plate. Replace the motor if necessary. ▶ Increase the motor speed if speed control is available.
X	X	-	X	-	-	-	-	-	Magnetic coupling has parted	▶ Switch off pump and switch on again.
X	X	-	X	-	X	-	-	-	Intake / suction pipe, pump or suction strainer blocked or encrusted	▶ Clean intake/suction pipe, pump or suction strainer.
X	X	-	X	-	X	-	-	-	Air is sucked in	▶ Seal source of problem.
X	X	-	X	-	X	-	-	-	Proportion of gas too high: pump is cavitating	▶ Consult the manufacturer.
X	X	-	X	-	X	-	-	-	Pump running in the wrong direction	▶ Change over any two phases in the motor.
X	X	-	X	-	X	-	-	-	Impeller out of balance or blocked	▶ Dismount the pump and inspect it for dry-running damage. ▶ Clean the impeller.
X	X	-	-	X	X	-	-	-	Pressure pipe blocked	▶ Clean the pressure pipe.
X	-	-	-	-	X	-	-	-	Suction pipe and pump not correctly vented or not completely filled	▶ Completely fill and vent pump and/or pipe.
X	-	-	-	-	-	-	-	X	Standstill, plain bearing stuck	▶ Disassemble the pump and carefully free the plain bearing rings.
-	X	-	X	-	X	-	-	-	Cross section of suction pipe too narrow	▶ Increase cross section. ▶ Clean encrustation from suction pipe. ▶ Fully open the fitting, if installed.
-	X	-	X	-	X	-	-	-	Hydraulic parts of the pump dirty, clotted or encrusted	▶ Dismount the pump. ▶ Clean the parts.
-	X	-	X	-	X	-	-	-	Suction head too large: $NPSH_{pump}$ is larger than $NPSH_{system}$	▶ Increase pump inlet pressure. ▶ Consult the manufacturer.
-	X	-	X	-	X	-	-	-	Back pressure of the system is too high, pump selected is too small.	▶ Consult the manufacturer.
-	X	-	X	-	X	-	-	-	Pump parts worn	▶ Replace the worn pump parts.
-	X	-	X	-	X	-	-	-	Pump jammed	▶ Consult the manufacturer.
-	X	-	X	-	X	-	X	-	Motor running on 2 phases	▶ Check the fuse and replace it if necessary. ▶ Check the cable connections and insulation.

Fault number									Cause	Remedy
1	2	3	4	5	6	7	8	9		
-	X	-	X	-	X	-	-	X	Temperature of fluid is too high: pump is cavitating	<ul style="list-style-type: none"> ▶ Increase pump inlet pressure. ▶ Lower temperature. ▶ Contact the manufacturer.
-	X	-	X	-	-	-	-	X	Viscosity or specific gravity of the pumped liquid outside the range specified for the pump	<ul style="list-style-type: none"> ▶ Consult the manufacturer.
-	X	-	X	-	-	-	-	X	Geodetic differential head and/or pipe flow resistances too high	<ul style="list-style-type: none"> ▶ Remove sediments from the pump and/or pressure pipe. ▶ Install a larger impeller and consult the manufacturer. ▶ Reduce the system pressure.
-	X	-	-	X	X	-	-	-	Pressure-side fitting not opened wide enough	<ul style="list-style-type: none"> ▶ Open the pressure-side fitting.
-	-	X	X	-	X	-	X	-	Pressure-side fitting opened too wide	<ul style="list-style-type: none"> ▶ Throttle down at the pressure-side fitting. ▶ Machine the impeller down. Consult the manufacturer and adjust the impeller diameter.
-	-	X	-	X	-	-	-	-	Viscosity lower than expected	<ul style="list-style-type: none"> ▶ Machine the impeller down. Consult the manufacturer and adjust the impeller diameter.
-	-	X	-	X	X	-	X	-	Motor speed too high	<ul style="list-style-type: none"> ▶ Compare the required motor speed with the specifications on the pump type plate. Replace the motor if necessary. ▶ Reduce the motor speed if speed control is available.
-	-	X	-	X	X	-	X	-	Impeller diameter too large	<ul style="list-style-type: none"> ▶ Throttle down the flow rate at the pressure-side fitting. Observe the minimum flow rate. ▶ Machine the impeller down. Consult the manufacturer and adjust the impeller diameter.
-	-	X	-	-	X	-	X	-	Geodetic differential head, pipe flow resistances and/or other resistances lower than specified	<ul style="list-style-type: none"> ▶ Throttle down the flow rate at the pressure-side fitting. Observe the minimum flow rate. ▶ Machine the impeller down. Consult the manufacturer and adjust the impeller diameter.
-	-	-	-	-	X	X	X	-	Pump distorted	<ul style="list-style-type: none"> ▶ Check the pipe connections and pump attachment.
-	-	-	-	-	X	-	-	-	Pipes and fittings blocked	<ul style="list-style-type: none"> ▶ Disassemble and clean the pipes and fittings.
-	-	-	-	-	X	-	X	-	Plain bearing faulty	<ul style="list-style-type: none"> ▶ Change the plain bearing (→ 7.2.2 Check the plain bearings and replace them , Page 18).
-	-	-	-	-	-	X	-	-	Connecting bolts not correctly tightened	<ul style="list-style-type: none"> ▶ Check all connecting screws and tighten them to the specified torque (→ 9.3.4 Tightening torques, Page 30).
-	-	-	-	-	-	X	-	-	Faulty housing seal	<ul style="list-style-type: none"> ▶ Replace the housing seal.

Tab. 7 Troubleshooting list

9 Appendix

9.1 Parts

9.1.1 Part numbers and designations

Part no.	Designation
1	Exhaust cap
2	Hexagon socket screw
3	Flange (suction side)
4	O-ring
5	Filler cap with O-ring
6	Housing seal
7	Partition
8	O-ring
9	Filter
10	Rear pump housing
11	Flange (pressure side)
12	O-ring
13	Impeller
14	Bearing bush
15	O-ring
16	Rear cover
17	Pump support
18	Hexagon head bolt
19	External magnet

Tab. 8 Designation of components according to part numbers

9.1.2 Part numbers and designations

Each spare part can consist of multiple constituent parts. The corresponding part numbers are listed separately (→ 9.1.1 Part numbers and designations, Page 26).

Spare part no.	Designation	Part no.
1	Flange, suction side	3, 4
2	Flange, pressure side	11, 12
3	Front pump housing	1, 5
4	Housing seal	6
5	Rear pump housing	8, 10
6	Fastening material	2, 12, 18
7	Impeller	13
8	Rear cover gasket	15
9	Rear cover	16
10	Magnet bell	19
11	Pump support	17

Tab. 9 Designation of spare parts by spare part no.

9.1.3 Drawings
Sectional drawing




Fig. 8 Parts (sectional drawing)

Exploded drawing

Spare part numbers are described in brackets.




Fig. 9 Parts (exploded drawing)

9.2 Installation example

The following example pipe schematic shows the main components of a pump installation.





Fig. 10 Installation example

- | | | |
|----------------------------------|--------------------------------|----------------|
| 1 Shut-off valve (pressure side) | 5 Shut-off valve (ventilation) | 9 Suction pipe |
| 2 Pipe fixture | 6 Exhaust line | 10 Strainer |
| 3 Foot valve or check valve | 7 Compensator | 11 Tank |
| 4 Pressure gauge | 8 Vacuum gauge | |

9.3 Technical specifications

9.3.1 Ambient conditions


 Operation under any other ambient conditions should be agreed with the manufacturer.

Temperature [°C]	Relative humidity [%]		Installation height above sea level [m]
	Long-term	Short-term	
5 to +40 ¹⁾	≤ 85	≤ 100	≤ 1000

Tab. 10 Ambient conditions

1) material-dependent

9.3.2 Total pressure

 Total pressure = system pressure + pressure build-up in the pump




Fig. 11 Total pressure, pump head material PP

SMP size ...	Total pressure [bar]
130	1.58
150	2.4
170	3.68

Tab. 11 Total pressure

9.3.3 Installation dimensions

The end of the motor shaft and the inner surface of the external magnet (19) must be flush:




Fig. 12 Installation dimension

A End of motor shaft and external magnet (19)

9.3.4 Tightening torques

Comply with the following tightening torques and use a torque wrench:

Housing screws

SMP size ...	Tightening torque [Nm]
130	3
150	3
170	5

Tab. 12 Tightening torques of casing screws

Flange screws

Max. 17 Nm

9.3.5 Pump housing fill volume

SMP size ...	Fill volume [l]
130	5.7
150	5.7
170	8.0

Tab. 13 Pump housing fill volume

9.3.6 Flow rate, delivery head, suction head after 180 s and minimum flow rate

SMP size ...	Motor power rating [kw]	Max. suction head [m]	max. flow rate [m ³ /h]	Max. differential head [m]	Minimum flow rate [m ³ /h]
130	0.37	4.5	13.4	10.5	0.2
150	0.75	5.5	17.1	15	0.5
170	1.5	6.5	23.8	24.5	0.7

Tab. 14 Flow rate, delivery head, suction head after 180 s and minimum flow rate

9.3.7 Weights

SMP size ...	Weight* [kg]
130	22
150	33
170	45


Tab. 15 Weights

*) Weight depends on choice of material, immersion depth and motor design. All data are approximate values.

9.3.8 Cleaning agents

- Weakly alkaline soap solution
- Steam jet (only for individual parts)

9.4 Maintenance schedule

 The manufacture recommends shorter maintenance intervals if the medium being conveyed contains solid matter. The operating company should choose the maintenance intervals appropriate to the medium being conveyed.

Interval	Designation	Action
Daily	Conveyed fluid	<ul style="list-style-type: none"> ▶ Check temperature. ▶ Check discharge pressure.
	Tank	<ul style="list-style-type: none"> ▶ Check the fill level.
Weekly	Operating temperatures	<ul style="list-style-type: none"> ▶ Check motor temperature.
	Pump	<ul style="list-style-type: none"> ▶ Check the pump for leaks and vibration.
Quarterly	Undoable screwed connections	<ul style="list-style-type: none"> ▶ Check all connecting screws and tighten them to the specified torque (→ 9.3.4 Tightening torques, Page 30).
	Impeller	<ul style="list-style-type: none"> ▶ Check the impeller for dirt and damage: <ul style="list-style-type: none"> – If the impeller is dirty, clean it. – If the impeller is damaged, replace it.
Annually	Plain bearing	<ul style="list-style-type: none"> ▶ Check the plain bearing for damage and change it if necessary (→ 7.2.2 Check the plain bearings and replace them , Page 18).
	Housing	<ul style="list-style-type: none"> ▶ Check the housing and housing seals for damage and change them if necessary (→ 7.3 Dismounting, Page 20).
	External magnet	<ul style="list-style-type: none"> ▶ Check the external magnet for correct and secure fitting (→ 9.3.3 Installation dimensions, Page 30).
As required	Motor	<ul style="list-style-type: none"> ▶ Check the motor against the supplier's documentation and perform maintenance if necessary (→ 1.2 Other applicable documents, Page 4).

Tab. 16 Maintenance schedule

9.5 Declaration of conformity

EU Declaration of Conformity




Manufacturer **SCHMITT-Kreiselpumpen GmbH & Co. KG**
Einsteinstrasse 33
D-76275 Ettlingen

Type of pump **Centrifugal pump**

Pump type **SMP 130, SMP 150, SMP 170**

We declare that the design of the listed pumps satisfies the provisions of the EU Directives.
The relevant points satisfy the requirements of the

EC Machinery Directive	2006 / 42 / EC
Low Voltage Directive	2014 / 35 / EU
Electromagnetic Compatibility	2014 / 30 / EU
Harmonized standards applied	EN ISO 12100:2010 EN 809:1998+A1:2009+AC:2010



Ettlingen, March 2025, **Moritz Klug**
Einsteinstrasse 33, 76275 Ettlingen
Managing Director / Documentation Officer
SCHMITT-Kreiselpumpen GmbH & Co. KG